

Assembly instruction

Blackbird

To assemble wing, backplate and cylinder, place it on proper bedding.



Unscrew the wing nuts from the adapters bolts.

Loosen the cam-bands and soak them in water.

When soaked, thread them over the cylinder.



When the right position is found, tighten the webbing, close the latch and secure the end with the cordura lock.

The bolts should by now form a vertical line with the cylinders valve opening.



Mount the wing by letting the bolts pass through the eyelets.  
Choose the one pair that ensures optimal trim.



Mount the backplate in the same way.  
Check thoroughly that no part of the wing is squeezed in an unnatural way.  
Fasten the wing nuts. Press the backplate onto the cylinder and tighten them.



Finally, You may choose to fix the inflator to the harness by using the elastic band.

Webb harness routing



Crutchband routing



Waist band buckle routing



Webb routing cam lock buckle

